



# PTZ Connection Daisy chain and Direct run

## Daisy Chain:


Maximum unit Capacity is 32 including AU40B / Z controller box, maximum distance: up to 4000ft.



Termination Resistor is located on the board at the bottom of the PTZ cylinder:




switch the jumper to 1-2



## Direct Run:

For this system you don't need to switch the end camera to 120Ω and the maximum distance is 1000ft / camera run.



If you require longer runs we recommend using a data amplifier, local power will still be required.

**WECU Surveillance.com**  
P.O. Box 158  
Carstairs, Alberta, Canada T0M0N0  
**Ph:** 403.668.4758  
**Fax:** 403.668.4790  
**Email:** [info@wecusurveillance.com](mailto:info@wecusurveillance.com)  
**Website:** <http://www.wecusurveillance.com>